


# Preethi®

## perma.press 1000

### DI-504




1000 Watts / 230 Volts / 50 Hertz



# USER INSTRUCTIONS & WARRANTY CARD

## Instructions For Use

Read these Instructions for Use and have a good look at the illustrations before using the Iron.



## For Safe Ironing

- Never use the Iron if it is damaged in any way.
- Take care, always to switch the Iron off when not in use. Always remove the plug from the socket and then stand the Iron on its rear side. Take care that children do not touch the Iron or the main cord.
- Never immerse the Iron in water. Don't do so for cleaning either.
- Clean the sole plate of the Iron with a soft cloth before ironing for the first time.
- Check first to see whether ironing instructions are attached to the article being ironed. Follow these instructions in all cases.
- If the fabric consists of various kinds of fibers (for instance cotton with polyester), you must always select the lowest ironing temperature.
- Sort the fabrics, wool with wool, cotton with cotton, etc. Start ironing the fabrics requiring the lowest temperature and progress to the higher ones, as the iron heats up quicker than it cools down.
- Set the temperature with the thermostat. Then put the plug into the socket and stand the Iron on its rear side. After the Pilot Lamp goes off and illuminates again, the temperature is correct and you can start ironing.
- The Pilot Lamp will light up from time to time during ironing. This is not a problem and you can just continue ironing.

## Cleaning

The sole plate can be cleaned by just rubbing with a soft cloth.

### Take it easy on yourself...

Ironing need not be tiring, if you follow the hints below:

- Iron with a straight back. Adjust the ironing board to the correct height (handle of Iron must be on same level as elbow).
- There are ironing boards which allow you to sit while ironing. Keep your elbow over the ironing board and only move the arm when ironing.
- Just hold the Iron and move it over your clothes at an easy pace.

### Pressing and pushing the Iron is not necessary.

- If you iron slowly, it is less straining.
- Have good lighting at the ironing board. Bad lighting is very strenuous for the eyes.

---

**Preethi**

**perma.press 1000**

**ONE YEAR**

**WARRANTY CARD**

Date Sold: ..... SI. No.: .....

Purchaser's Name & Address: .....

.....

.....

Dealer's Name & Address: .....

.....

Signature:

Stamp:

**Preethi**

**perma.press 1000**

**SALE DETAILS**

**DI-504**

Date Sold: ..... Sl. No.: .....

Purchaser's Name & Address: .....

.....

.....

Dealer's Name & Address: .....

.....

.....

Signature:

Stamp:

Postage  
will be  
paid by  
addressee

## **BUSINESS REPLY CARD**

**Permit No.  
BRP/58  
Teynampet.**

No postage  
Stamp  
necessary  
if posted  
in India

**MAYA APPLIANCES (P) LTD.**  
No. 2, Boat Club, I Avenue,  
Chennai 600 028.

# TERMS & CONDITIONS

1. Retain original sale bill and Warranty card.
2. All repairs within One Year Warranty period (arising from manufacturing defects) will be done free of charge.
3. Free service and replacement under Warranty does not affect the expiry date of the Warranty.
4. Defective components which are exchanged both under chargeable and free of charge basis become the property of company.
5. Warranty does not cover non-stick coating on sole plate and scratches to the body.
6. This warranty is not valid, in case:
  - a. The iron is not used according to this manual.
  - b. Defects are caused by improper or reckless use.
  - c. Any repairs are done by persons other than Maya Appliances (P) Ltd.
  - d. Modifications of any nature are made in the iron.
  - e. This product is used for commercial purposes (i.e. other than domestic use).

---

Mfd. by: **PREETHI HIMAACHAL & CO.**  
Bharatgarh Road, Nalagarh 174 101. HP. INDIA.  
Tel: 01795-220 234 email: hp@preethi.biz

Mkt. by: **MAYA APPLIANCES (P) LTD.**  
2, Boat Club, 1st Avenue, Chennai 600 028. TN. INDIA.  
Tel: 044-2434 3344 email: info@preethi.biz